

Installation Guide

Inspect flooring product carefully for visible defects BEFORE INSTALLATION.

Acclimate flooring to appropriate site conditions. Follow UNI 11371-2017/NWFA for Acclimation on Jobsite. Maintain the temperatures of 15°C (60°F) to 25°C (80°F) and a humidity range of 30% to 50%..

Test the subfloor and jobsite itself, including ambient temperature/ relative humidity and all other variables that may adversely affect a wood floor. The Moisture Content (MC) of the wooden subfloor should be within 2% the MC of Legno Italiano flooring planks.

Legno Italiano wood flooring products are preferred to be installed using wood flooring adhesives. Please follow the instructions provided by the adhesive manufacturers.

For details of installation please refer to UNI 11371-2017 or NWFA Installation guidelines.

Legno Italiano can be installed over Water Heated Radiant Heat system. The temperature of the heating system should be raised gradually to avoid damaging the wood floor.

Maintenance

Use Vacuums and damp mops to clean Legno Italiano products.

Avoid direct sunlight exposure. Extended periods of direct sunlight exposure may damage the wood flooring.